



## 3. Power Supply Assembly

Written By: Ryan Lock



## Step 1 — Pre-Assembled Power Supply



- At this stage your PSU-Output-Power-Cable will be inserted inside the Y-Axis Drag Chain.
- Place the Power Supply at the Rear of the WorkBee CNC Machine next to this cable.
- Plug the PSU-Output-Power-Cable into the female connector on the Pre-Assembled Power Supply.
- Plug the mains cable into the IEC Inlet on the Pre-Assembled Power Supply.

⚠ Use the red switch on the side select the input voltage for your local power.

Thanks for following the guide. Any issues, please contact us!