

Assembling Your Original WorkBee Power Supply

Written By: Ryan Lock



Step 1 — Configure The Power Supply







⚠ Use the red switch on the side, select the input voltage for your local power.

- Place the power supply in an appropriate location for your needs.
- Plug the PSU Output Power Cable into the female connector on the Pre-Assembled Power Supply.
 - Connector the other end of the PSU Output Power Cable to your controller.
- Plug the mains cable into the IEC Inlet on the Pre-Assembled Power Supply.
 - Plug the other end of the mains cable into your wall socket
- Use the switch on the side of power supply to turn the power supply on.
 - Adjust the potentiometer to adjust the voltage.

Thanks for following the guide. Any issues, please contact us!